

Thank you for choosing Wellputt. We wish you the best in your golf practice and hope our Custom Surface enhances your skills and enjoyment.

## MAINTENANCE



### REGULAR CLEANING:

It is highly recommended to remove loose dust, dirt, and debris using a soft-bristle brush or a vacuum cleaner on a low setting. This ensures a smooth, clean practice surface.



### ROLL OF THE BALL:

Putting from the same starting point can create ball tracking over months and years. This is most often the case with fitting mats, therefore, we highly recommend you brush the mat regularly with a broom.



### LIQUID STAIN REMOVAL:

For liquid splashes, blot up as much liquid as possible with a clean, white cloth.

### SEMI-SOLID STAIN REMOVAL:

Gently scrape it away with a spoon or spatula, then dab it with a damp sponge.



### DIFFICULT STAINS REMOVAL:

For wine, coffee, tea, fruit juice, or other sweet drinks stains, mix 2 cups of water with a tablespoon each of white vinegar and dishwashing liquid. Use a clean white towel to apply the solution. Let it sit for a few minutes and blot it with a clean cloth or paper.

Always work from the outer edge of the stain toward the center. Never rub around a wet spill to avoid spreading the stain outside its original area. Persistent stains can be cleaned with a non-aggressive detergent and rinsed with clean warm water. Dry flat and avoid direct sunlight. Repeat if necessary. Avoid aggressive brushing, which can damage the fibers.

**Our mats have a rolling quality and speed that are as close as possible to a real green.**

**Stimpmeter speed: 10/11.5 ft - - 3m / 3.5m** (The speed is given as an indication and may differ according to the raw material batches during production. Wellputt isn't responsible for any difference in the rolling speed of the ball as specified in the General Terms of Use).

## SEND US PICTURES OF YOUR INSTALLATION & GET 10% OFF YOUR NEXT ORDER.

By sending pictures to us, you agree for them to be used for media purposes.

[www.wellputt.com](http://www.wellputt.com)  
[custom@wellputt.com](mailto:custom@wellputt.com)



WELLPUTT®

# THE MATKEEPER'S GUIDE

## INSTALLATION & MAINTENANCE



# 1 PUTTING TRAINING CONCEPTS

# INSTALLATION

Please be aware that WELLPUTT is not responsible for any damage that may occur to the mat during the installation process. While we provide detailed installation instructions, the responsibility for the proper installation and any associated risks lie with the purchaser or the individual performing the installation.

Thank you for purchasing a Custom Wellputt Surface! To ensure a smooth and successful installation, please follow these step-by-step instructions.







## PLEASE ACKNOWLEDGE THE FOLLOWING:

- These instructions are meant for a permanent installation.
- The base needs to be a flat and hard surface (wood, concrete, ceramic)
- Depending on where you place the mat, the floor may not be perfectly straight. This will affect the use of the mat. A self-leveling concrete may be necessary to obtain a 0% leveled surface if the ball should roll perfectly straight (please inquire with a professional).

## BEFORE YOU BEGIN:

- Ensure that the room where you plan to install the putting mat is dry and free of any debris or sharp objects.

## MATERIALS YOU WILL NEED:

 <p>1</p>	 <p>2</p>	 <p>3</p>	 <p>4</p>
Double-sided carpet tape or adhesive.	Padding* (0.3in / 8mm min)	Professional carpet adhesive (follow the instructions)	Utility knife or cutter.
 <p>5</p>	 <p>6</p>		
A straight edge or ruler.	A measuring tape or yardstick.		

\*to avoid bouncing balls and to give the user the feel of a reel putting green. It does not affect the ball speed

# INSTALLATION STEPS

We recommend using a professional installer for the best result.

## 1. PREPARE THE INSTALLATION AREA:

- Vacuum or clean the floor thoroughly to ensure no debris or dirt is trapped under the mat.

## 2. PLACE THE PADDING:

- Unroll and position the underlay perpendicular to the direction of the putting mat that will come on top. (to avoid it moving)
- Tape the underlay with double-sided carpet tape or adhesive. Make sure the room's corners are fully covered and well taped down.

## 3. UNROLL AND POSITION THE MAT:

- Unroll the putting mat in the desired location within the room.
- Let it sit flat at least 24 hours to allow it to acclimate to the room's temperature and flatten any potential creases.
- Adjust the mats to ensure it is evenly centered and aligned with the room's layouts.
- To avoid gaps between the mat and wall, make sure to leave an extra 1cm / 0.4 inches of mat all around the room's edges.
- If you plan to make a hole in the ground for your mat, mark the hole on the floor with a permanent marker - do it once the mat is perfectly unrolled and placed - remove the mat and start cutting it out. Once done, replace the mat in its desired place.

## 4. SECURE THE EDGES:

- Starting from one edge, lift the mat slightly and apply professional carpet adhesive all along the mat's underside.
- Press the mat down gently onto the glue, to avoid deforming the mat. To ensure it adheres securely to the floor you can use the cardboard tube to apply even pressure.

## 5. SEAM ALIGNMENT (IF APPLICABLE):

- If your Custom Surface has multiple sections or seams, align them carefully to create a seamless look. Use a straight edge or ruler to ensure precision.
- Apply professional carpet adhesive under the seams for added stability.

## 6. TRIM EXCESS MATERIAL:

- Use a utility knife or cutter to trim any excess material along the perimeter of the mat, ensuring a clean and flush fit with the room's walls.
- We highly recommend placing threshold bars around the room for a professional look.

## 7. TEST AND PRACTICE:

- Once the mat is securely in place, test its alignment and practice your putting skills. Make sure the maintenance advice is correctly followed to ensure a quality ball speed.

If you encounter any issues during the installation process, do not hesitate to contact our Wellputt team at [custom@wellputt.com](mailto:custom@wellputt.com).